

Test Results

December 10, 2021

Туре	Photodetector Module	
Model	DXM30AF	
Serial Number	U00626	
Dark Current	1	nA
Responsivity @ 850nm SM	0.51	A/W
Optical Return Loss @ 850nm SM	-31	dB
Responsivity @ 1550nm SM	0.76	A/W
Optical Return Loss @ 1550nm SM	-22	dB
FWHM	14.2	ps
3 dB Bandwidth	33.3	GHz
QA		

Additional test data and all other documentation may be found at www.thorlabs.com/manuals (by Model and Serial #)



Caution: This is an ESD Sensitive Component.

Take all appropriate precautions to discharge personnel and equipment before making any electrical connections to the unit. This especially applies to coaxial connecting cables that can accumulate capacitve charge.